

Operation procedure

- Connect power cable to the portable cooler bag power socket.
- Connect the other end of the power cable to the cigarette-lighter socket.

Note

- Please use extreme care when connecting and disconnecting the unit. To avoid risk of electric shock, do not insert any metal objects or any parts of your body into the lighter socket.
- Remember to turn of the cooler and empty contents when not in use.

Precautions

- Please ensure that the cooler bag is adequately ventilated. When using in a vehicle or indoors, do not obstruct or block the backside of the unit. Allow a minimum of 4 inches/10 centimeters free space for proper ventilation.
- When the portable cooler bag is used in a vehicle, users are strongly advised to turn off and/or disconnect the unit when the vehicle engine is turned off. Failing to observe this will cause the vehicle battery to excessively be discharged.
- When used in a vehicle, please take care when opening the compartment, as the contents may have shifted during travel.
- Ensure all power source connections are connected properly and securely.
- The cleaning and maintenance of the cooler bag can be done with a soft damp cloth. To remove stains, use a mild soap and a damp cloth.
- If the cooler bag is not used for prolonged period of time, disconnect all power source connections and empty the contents of the unit.

